

# IMPORTANT

## ***CENTERFORCE FLYWHEELS***

### **ALL FLYWHEELS**

All CENTERFORCE flywheels have a preservative on them to help prevent rust. We recommend that you use BRAKE CLEAN to remove all traces of the preservative prior to installing the clutch assembly.

**Failure to do so may cause slippage and premature clutch failure**

**NOTE:** Replacement of any Dual-Mass flywheel with a Single-Mass Flywheel may result in unwanted gear noise from the transmission.



CENTERFORCE  
**DUAL** FRICTION



**DYAD**  
QUALITY ENGINEERED MULTI DISC CLUTCH SYSTEMS



**LMC**  
SERIES

**CENTERFORCE FLYWHEELS**

**"NOTE"** Centerforce tip sheets are for general reference only. Please refer to your owners manual for vehicle specifications.

# IMPORTANT

### **Dodge Flywheel Installation Tips**

A small amount of Threadlocking compound is recommended on the enclosed flywheel bolts.

DO NOT use a washer with these flywheel bolts.

Tighten all bolts evenly, 1/4 turn at a time in a crisscross pattern until the flywheel is completely drawn-up to the crankshaft.

Torque all bolts in 3 steps:

First to 30 ft/lbs. Then 70 ft/lbs.

FINAL TORQUE TO 105 ft/lbs.

Note: M12 x 1.25 Threads